



# Hydraulic Tilt Pole Guide Interlock



- Protects both the tilt pole guide and the boom from accidental damage caused by extending the upper boom while the tilt pole guide is on the intermediate boom and tilted downward
- How it works... When the tilt pole guide is tilted down, the activation plunger allows a poppet valve to release and bypass oil from the upper boom valve, causing the upper boom extension to be inoperable until the tilt pole guide is tilted up. When pole guide is tilted up, the upper boom can be extended.